



PARTS LIST



Memory Craft 4800


PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	841601008	Top cover unit
2	841602009	Top cover unit
3	841004005	Top cover
4	841005006	Chart board
5	841006007	Top cover body
6	730501022	Bobbin winder thread guide unit
7	840138006	Top cover thread guide
8	000160102	Adjustable nut 4
9	822016609	Spool pin
10	822017002	Pin
11	822018003	Spring
12	000107318	Tapping screw 3x8B
13	753502002	Top cover thread guide holder unit
14	693093006	Flat screw
15	000062701	Nut
16	687022005	Bobbin winder stopper
17	000066727	Setscrew 3x8
18	630005006	Nut
19	830013003	Top cover hinge
20	000101404	Setscrew 4x6
21	830190005	Washer
22	754044004	Foot container
23	000120214	Tapping screw 3x8B
24	822020503	Spool holder
25	753620007	Handle unit
26	753121003	Handle
27	753122004	Handle plate
28	000120502	Flat tapping screw 3x8B
29	000080901	Setscrew 4x25
30	000078319	Setscrew 3x6
31	840119001	Handle set plate (rear)
32	000081005	Setscrew 4x8
33	827602108	Bed cover unit
34	827004104	Bed cover
35	753005000	Drop lever
36	000013903	Snap ring CS-5
37	000101703	Setscrew 4x12
38	840136004	Cord guide
39	841501007	Extension table unit
40	841604207	Face cover unit (JAI)
	841604001	Face cover unit (JNZ), (JUK), (JEG)
	841604403	Face cover unit (JA)
41	841008009	Face cover
42	840602006	Thread cutter unit
43	830312016	Caution sticker (JAI only)
44	731067002	Face cover spring
45	827099003	Face cover sticker
46	366501102	Face cover hinge
47	000081119	Setscrew 4x6
48	000120203	Tapping screw 3X8B
49	100411001	Lamp sticker (JAI), (JA)
50	659601007	Free arm cover (unit)
51	659001001	Free arm cover
52	000120203	Tapping screw 3X8B
53	756004008	Free arm cover set plate
54	000101404	Setscrew 4x6


PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	840620103	Front set plate unit
2	840108007	Front set plate
3	830510304	Photo interrupter unit
4	827090004	Sensor set plate
5	000103808	Setscrew 3x5
6	827630013	BH lever unit
7	000002105	Snap ring E-3
8	830057010	BH lever guide
9	830538113	Lamp socket unit
10	000081005	Setscrew 4x8
11	841007008	Handle set plate (front)
12	827018019	Lamp set plate
13	000101507	Setscrew 3.5x5
14	827609208	Needle bar supporter unit
15	827026009	Needle bar supporter
16	840137005	Needle bar supporter pin
17	673022002	Spring washer
18	000070609	Plain washer 6
19	000002507	Snap ring E-4
20	000111902	Hexagonal socket screw 3x4
21	734093017	Threader shaft spring
22	000122906	Guide pin
23	734107004	Base plate
24	827091005	Threader shaft spring
25	653036029	Threader guide plate
26	734096009	Threader lever
27	734097000	Threader knob
28	000097602	Setscrew 2x4
29	734515009	Threader guide plate
30	000105501	Setscrew 1.6x2.5
31	734625003	Threader set plate unit
32	734101008	Threader set plate
33	734102009	Threader base plate
34	000111902	Hexagonal socket screw 3x4
35	653503103	Needle bar unit
36	653612003	Needle bar conn. stud unit
37	653504001	Needle bar conn. stud unit
38	650040005	Felt
39	650041006	Felt set spring
40	829027006	Supporter guide plate
41	000101105	Setscrew 3x4
42	000111201	Hexagonal socket screw 4x4
43	827083004	Pin
44	000053008	Cord binder
45	827092006	Supporter spring
46	102408089	Needle HA1-14


PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	820511108	Take up lever unit
2	650062003	Take up lever pin
3	000111201	Hexagonal socket screw 4X4
4	000002806	Snap ring E-6
5	652512009	Needle bar crank pin unit
6	827518106	Upper shaft unit
7	102073003	Setscrew
8	761052007	Setscrew
9	000111304	Hexagonal socket screw 5X5
10	000111304	Hexagonal socket screw 5X5
11	830095009	Upper shaft shield plate 5
12	820102009	Plate washer
13	000081005	Setscrew 4X8
14	673062004	Bushing
15	732026002	Adjusting wheel
16	650071005	Timing belt
17	653055002	Declutch release ring
18	653056003	Declutch ring
19	653057004	Clutch spring
20	653058005	Belt wheel
21	653139012	Timing belt
22	000038605	Washer FT100
23	830286009	Hadwheel base plate
24	653061115	Hadwheel
25	841605002	Thread tension unit
26	000101404	Setscrew 4X6
27	000101703	Setscrew 4X12
28	000030205	Snap ring E-8
29	731384008	Felt


PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	841606003	Front panel unit
2	841011108	Front panel
3	841013100	Button 1
4	841036109	Button 2
5	841014204	Button 2
6	841014307	Button 2
7	841014400	Button 2
8	841014503	Button 2
9	841014606	Button 2
10	841014709	Button 2
11	841015102	Button 3
12	841015205	Button 3
13	841015308	Button 3
14	841015401	Button 3
15	841607004	Print board K unit
16	841018000	Adjusting knob
17	000120203	Tapping screw 3X8B
18	841017001	Speed setting lever
19	751273005	Speed setting lever cover
20	000120203	Tapping screw 3X8B
21	653507602	Slide volume unit
22	000014306	Snap ring CS-3
23	841018105	Button 4
24	841018208	Button 4
25	841018301	Button 4
26	840518004	Print board F unit
27	000107905	Tapping screw 3x6B
28	827067002	Front panel set plate (front)
29	841019003	Front panel set plate (rear)
30	000115205	Setscrew TP 4x6
31	000103808	Setscrew 3x5
32	000101404	Setscrew 4x6
33	000103509	Setscrew 4x10
34	841608407	Print board A unit
35	841504402	Print board A unit
36	827070008	"A" Board isolation paper
37	827071009	"A" Board set plate (top)
38	827072000	"A" Board set plate (bottom)
39	000161103	Tapping screw 3x6B
40	000081005	Setscrew 4x8
41	832209015	Emblem
42	841012109	LCD panel frame


PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	840604008	Stepping motor (feed) unit
2	000115205	Setscrew TP 4X6
3	000002105	Snap ring E-3
4	827003000	Base
5	827601107	Arm leg unit
6	827002102	Arm leg
7	000061412	Nut
8	000097901	Setscrew 5x18
9	735002001	Rubber base
10	000066808	Setscrew 6x14
11	647009002	Bed rubber base
12	000120203	Setscrew 3x8B
13	000103509	Setscrew 4x10
14	824058001	Base cap
15	841001002	Rear cover
16	000104119	Setscrew 4x20
17	000115205	Setscrew TP 4x6
18	751612206	Lower shaft unit
19	751148000	Feed cam
20	000115009	Setscrew TP 3x8
21	650076000	Lower shaft toothed wheel
22	000111304	Hexagonal socket screw 5x5
23	753183025	Feed lifting cam
24	686035008	Feed lifting cam spring
25	820166001	Ring
26	000111201	Hexagonal socket screw 4x4
27	000038502	Washer
28	650078002	Bushing
29	735143005	Felt
30	820161006	Pin
31	822112008	Felt holder 1
32	822070003	Felt 1
33	650079003	Bushing
34	000107318	Tapping screw 3x8B


PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	750036012	Slide plate
2	102261000	Bobbin
3	627569209	Bobbin holder unit
4	681009101	Setscrew
5	756604107	Needle plate unit
6	752005007	Slide plate set plate (left)
7	825015010	Slide plate set plate (right)
8	825016000	Slide block
9	825017001	Slide block spring
10	820374004	Setscrew 2x2.3
11	000122504	Guide pin
12	827011001	Reverse rotation stopper
13	810220003	Setscrew
14	627567001	Rotation stopper
15	000122700	Guide pin
16	822065005	Pressure dial
17	840120005	Pressure adjusting cam holder
18	686027007	Pressure adjusting cam (1)
19	686028008	Pressure adjusting cam (2)
20	840129004	Presser spring
21	735028003	Presser bar bracket
22	000111500	Hexagonal socket screw 4x8
23	827021004	Presser bar
24	829515006	Presser foot unit
25	753199002	Thumb screw
26	841010004	Arm thread guide
27	000101404	Setscrew 4x6
28	827622012	ZZ rod unit
29	827055018	ZZ rod
30	827088009	ZZ rod spring
31	820373003	Setscrew 2x3
32	000078319	Setscrew 3x6
33	678084007	Eccentric pin
34	653037008	Washer
35	828605001	Presser bar base unit
36	827020014	Presser bar base
37	827082003	Presser bar set plate
38	000066303	Hexagonal bolt 4x6
39	000070908	Washer 4
40	810220003	Setscrew
41	000081005	Setscrew 4x8
42	735029004	Presser foot lever
43	827022005	Tension release lever
44	827023006	Tension release lever
45	832523007	Zigzag foot unit
46	804509000	Presser foot holder unit


PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	834527100	Feed rock shaft unit
2	840005003	Feed dog
3	000104005	Setscrew
4	738055008	Center screw
5	000111304	Setscrew
6	650085002	Spring
7	650612004	Feed adjuster unit
8	000036603	Washer
9	821311009	Felt
10	625144002	Bushing (front)
11	650175000	Washer
12	000111201	Hexagonal socket screw 4X4
13	820387000	Ring
14	000111108	Hexagonal socket screw 4X6
15	840603007	Feed shaft unit
16	840006004	Feed shaft
17	000160102	Adjustable nut 4
18	825261002	Feed adjusting arm 2
19	589040002	Spring
20	827043105	Feed adjusting arm 1
21	810207004	Spring washer
22	827086007	Feed adjusting arm screw
23	000115906	Setscrew TP
24	650092002	Bushing (rear)
25	827614011	Hook race unit
26	820123006	Hook race shaft
27	820124007	Oil string 1
28	820125008	Oil string 2
29	000038409	Washer
30	650623008	Hook body unit
31	627191000	Thread guard
32	820374004	Setscrew 2X2.3
33	627192001	Washer
34	625102008	Washer
35	827040009	Cover
36	823106002	Hook race set plate
37	000107204	Setscrew 3X12B
38	650094004	Hook race shaft base
39	000081005	Setscrew 4X8
40	650171006	Set plate
41	000070506	Washer
42	000101404	Setscrew
43	627190010	Magnet
44	650172007	Hinge screw
45	000038409	Washer
46	000111304	Hexagonal socket screw 5X5

PARTS LIST



PARTS LIST

KEY NO.	PARTS NO.	DESCRIPTION
1	840608002	Stepping motor (ZZ) unit
2	827054006	Connecting arm
3	000002105	Snap ring E-3
4	830543100	Sensor unit
5	000081005	Setscrew 4X8
6	829505003	Transformer unit (120V) (JAI)
7	829508006	Transformer unit (240V) (JNZ)(JUK)(JA), (230V) (JEG)
8	000115205	Setscrew 4X6
9	829020009	Transformer supporter (for 120V only)
	827626304	Print board C unit (120V) (JAI)
	827626201	Print board C unit (240V) (JNZ)(JUK)(JA), (230V) (JEG)
10	000161206	Setscrew 3X10B
11	827628018	Motor unit
12	000115700	Setscrew TP 4x10
13	830575019	Machine socket unit (120V) (JAI)
	830576010	Machine socket unit (240V) (JNZ)(JUK)(JA), (230V) (JEG)
14	000121204	Setscrew 4X8B
15	000103509	Setscrew 4X10
16	653508005	Bobbin winder unit
17	823119008	Spring
18	841020007	Switch lever
19	000078319	Setscrew 3x6
20	686063005	Hinge screw
21	653134006	Declutch arm
22	625215005	Spring
23	625214004	Hinge screw
24	652611009	Idler unit
25	841021008	Belt cover
26	000104108	Setscrew 4x20
27	827085017	Belt cover set plate
28	827081002	Cord guide
29	000053008	Cord binding
30	000117908	Fuse AC125V, 2.5A (JAI)
	000143693	Fuse AC250V, 2A (JNZ), (JUK), (JEG), (JA)
31	000182177	Fuse AC250V, 3.15A (JAI)
	000144199	Fuse AC250V, 5A (JNZ), (JUK), (JEG), (JA)
32	000114709	Setscrew TP 3x6

